



If your downspout has a **STRAIGHT BACK** - Follow steps 1-3.  
(All you need is a pencil & a pair of household scissors to install)

- Slide insert into down spout smooth side down, ensuring insert lies flat until it hits the back.
- Mark any excess length and trim.
- Attach clip as shown.

If your downspout has a **CURVED BACK**

- Bend the insert so that it molds to the curved back, once it's molded, slide the insert into the downspout smooth side down then attach clip as shown.